- The operating controls are. (R) (L) (M) (R)
- Reset Left Middle Right
- (R) initializes and turns the unit on.
  - If (L). is held while resetting the back light is turned on.
- (M). Cycles through the operating modes when tapped.
  - When Held returns to display mode.
- (L) and (R) scroll through lists.
  - When Held in some modes perform selecting operations.
- The Modes are Display, Favorites, Line select, Trouble Codes, Options
  - Items in display can be selected in Line Select mode.
    - Tap (M) twice to Line 1 select mode. Using (L) and (R) scroll through the viewable items list.
    - When desired item is found Tap (M) once to go to line 2 select mode.
    - Using (L) and (R) scroll through the viewable items list.
    - When item desired is found transfer both items to display mode by Holding (M) this will also return unit to display mode.
  - To SAVE to one of the 7 Favorites locations. (Slot 7 is the default display item).
  - Tap (M) , Then (L) and (R) scroll through the favorites slots.
    - Hold (R) To save item in current location.
- To Recall a favorite to display.
  - Navigate to favorite location then hold (L) , the items are transferred to display and the unit returns to display mode.
- Options Mode
  - Tap (M) to navigate to options.
    - Tap (L) to cycle through list of options.
    - Tap (R) to change option setting.
      - NOTE; Holding (R) will reset item to the default setting.
    - Hold (L) to activate the option selected.
    - Hold (M) to return to display mode.
- Trouble Codes.
  - Tapping (M) navigate to Trouble Codes. Then (L) and (R) scroll through the ECU'S
    - Hold (R) to start retrieving trouble codes.
      - (L) and (R) will scroll through the ECU'S and retreve codes.
- To Clear Codes
  - Option to clear must be set
  - Select desired ECU, hold (L).
    - Confirm choice by holding (L).
  - Abort by tapping any other button.
  - Hold (M) to return to Display mode.